

Assembly Instructions

HSK-M-EMV / METRICA-M-EMV



Step 1



- + Strip cable
- + Expose braided shield

Step 2

- + Feed cable through dome nut and clamping insert
- + Fold braided shield over clamping insert
- + Make sure that braided shield overlaps the O-Ring by 3/32" (2 mm)



Step 3



- + Push clamping insert into body and tighten dome nut
- + Assemble into housing
- + Finished!

