

Assembly Instructions

Right angle connector with positioning

1.

2.



3.

4.



5.



6.



7.

8.